




Thistle Wall Stay Fitting Instructions

Contents



Measure the distance from the wall to where the back of the radiator is to sit, as shown above. The Clamping Plate can be used in either a vertical or horizontal position. Radiators with a smaller space between each section, the Clamping Plate should be positioned Vertically. Radiators with a larger space between each section, the Clamping Plate should be positioned horizontally. Install the red washer, then the Thistle head will screw through the un-threaded clamping plate.

